




Set the Mode Dial to <M>.

Set the ISO speed

Set the shutter speed and aperture.



Standard exposure index




Exposure level mark

• To set the shutter speed, turn the



dial.

• To set the aperture, hold down the



button and turn the



dial

Focus on the subject.

- Press the shutter button halfway.
- The exposure setting will be displayed in the viewfinder.




• The exposure level mark

indicates how far the current exposure level is from the standard exposure level.

Set the exposure and take the picture.

- Set the shutter speed and aperture as desired.
- If the exposure level exceeds ± 2 stops from the standard exposure, the end of the exposure level indicator will



display

or

in the viewfinder.

the

icon will blink at where

<-3> or <+3> is displayed.)

[📷 2: Auto Lighting Optimizer]

- If [Auto Lighting Optimizer] is set to any setting other than [Disable], the image may still look bright even if a darker exposure has been set.
- If ISO Auto is set, the ISO speed setting will change to suit the shutter speed and aperture in order to obtain the standard exposure. Therefore, you may not obtain the desired exposure effect.